

## Espadrille



Tan PIPING

1. Pipe a line along the bottom edge of the shoe cookie.



Tan PIPING

2. Pipe a line parallel to the bottom line and connecting the dots on each end of the cookie (See video to learn how to mark-up your cookie). Pipe two smaller lines along the sides to close the shape of the sole.




Tan PIPING

3. Outline the "toe" by connecting the three dots near the front of the shoe.



Tan PIPING

4. Pipe squiggles inside the sole and toe in order to help minimize cratering of flood icing.



Navy PIPING

5. Pipe a line from the top left corner of the shoe to the dot/point indicated.




Navy PIPING

6. Pipe a line along the left edge of the shoe from the top of the sole to the top corner.




Navy PIPING

7. Pipe a line along the top edge of the sole's upper border, making sure the lines are touching but not overlapping.



Navy PIPING

8. Pipe a hooked line that creates a border between the front and back of the shoe (as shown). This line will start at the upper-left dot, intersect the middle dot and end at the bottom dot.



Navy PIPING

9. Pipe a line along the top edge of the cookie from the upper point of the shoe to the toe. Pipe a second line along the left edge of the toe's outline.


\*This step is not essential but does help create a more defined crease.

## Espadrille (cont.)



Tan FLOOD

10. Fill in the sole of the shoe, using your scribe to pull icing into each corner.




White FLOOD

11. Fill in the "interior" section of the shoe, using your scribe to pull icing to the edges and into the tight angles.



12. Allow your cookie to dry or, at a minimum, crust over.



Navy FLOOD

13. Fill in the front "fabric" section of the shoe.



White FLOOD

14. With the base icing still wet, tap the tip of your flood bag against the surface to make a dot (apply next to no pressure on the bag). Repeat to create a pattern like the one shown.



15. Allow your cookie to dry or, at a minimum, crust over.



Navy FLOOD

16. Fill in the back "fabric" section of the shoe.



White FLOOD

17. With the base icing still wet, tap the tip of your flood bag against the surface to make a dot (apply next to no pressure on the bag). Repeat to create a pattern like the one shown.



Tan FLOOD

18. Fill in the toe of the shoe.

## Espadrille (cont.)



19. Allow your cookie to dry for at least 3-4 hours or ~20 minutes in a dehydrator.



Tan PIPING

20. Pipe a line down the middle of the shoe's sole from one edge of the cookie to the other.



Tan PIPING

21. Pipe pairs of forward slanted lines along the bottom portion of the sole. Pipe each line from the bottom edge up to the mid-line of the sole.



Tan PIPING

22. Pipe pairs of backward slanted lines from the top edge of the sole to the mid-line.



Tan PIPING

23. Pipe a series of small lines (or "stitch" marks) on the toe of the shoe.




Tan PIPING

24. Pipe pairs of small "stitches" that span the space between the fabric section of the shoe and the sole.



Navy PIPING

25. Pipe a line along the top edge of the back "fabric" section of the shoe.



Navy PIPING

26. Pipe a line along the border between the front and back sections of the shoe.



Navy PIPING

27. As one final detail, pipe an "X" stitch on the border between the front and back of the shoe.